

## **Water Mold - Decontamination Process:**

(This came as a fax to a local spa store from Leisure Time chemical company regarding water mold-white flakes)

1 – Remove filter(s), soak in a (5) gallon bucket with 2 tsp of Sodium Dichlor (Granular Spa Chlorine). After soaking 2-3 hours rinse thoroughly. It is highly suggested to buy new filters. You will leave filter(s) out during this process.

2 – Add 2.5 ounces of Sodium Dichlor for every 100 gallons of water.

3 – Turn on the jets and aerator and run for (30) minutes. Then turn both on and off every (5) minutes 4-5 times during the next hour.

4 – After (8) hours, test for proper chlorine level, which should be 5-10 on test strip (purple).

5 – Drain the spa and back-flush by filling the foot-well with the garden hose in the filter area, then drain this water out as well.

6 – Put in clean or new filter(s) and fill the spa.

P.S. Water mold could be coming from your garden hose. Put (1)tsp of chlorine granules down the faucet end of garden hose, shut off other end, connect back to faucet and fill with water, let stand (20) minutes, then flush out.